









- **Twin™ Shoes are applied in a similar way** as traditional one-piece steel shoes
- **The additional pre-cut and final cut steps** are easily completed with off-the-shelf hand and power cutting tools
- **Spring-clamp style shoe vises safely hold** the shoe during pre-cutting of the support and ground side of the shoe
- **Bartek hoof mapping guides and shoe gap monitoring gauges** support planned and consistent hoof care management



Shoeing Step	Tool Types Recommended	Example(s)
1. Clean & Trim	Standard Farrier Tools	----
	Hoof Mapping Guide with Fine Point Markers 	<ul style="list-style-type: none"> • Bartek Hoof Mapper™ #HM-TR1FM <p><i>Markers:</i></p> <ul style="list-style-type: none"> • Milwaukee Inkzall #48-22-3100 for Sole balance marking • Dry Erase Marker for Hoof Tracing on Mapper
2. Fitting	Standard Farrier Tools	----
	Rasp – Half Round w/ square edge (For seating front clips and squaring the hoof wall recess) 	<ul style="list-style-type: none"> • Save Edge 14" Half Round Bastard File
	Nipper – Half Round (For seating front clips) 	<ul style="list-style-type: none"> • Nordic Viking 12" Half Round Nipper • G.E. 12" Half Round Nipper
2A. Pre-Cut	Shoe Vise - Spring Clamp Style 	<ul style="list-style-type: none"> • NC Tool - Anvil Stand with Vise
	Angle Grinder 4-1/2" / 5" (with 0.040" (1mm) thick metal cutoff wheel) 	<ul style="list-style-type: none"> • Milwaukee M18 #2880-20 (Bare Tool) • Milwaukee M18 #2880-22 (Kit) • (Also standard Farrier's rig Band Saw) <p><i>Metal Cutoff Wheel:</i></p> <ul style="list-style-type: none"> • Diablo #DBD050040101F <p>Type 1, 5" Dia, 0.040" (1mm), 7/8" Arbor</p>

Continued

Shoeing Step	Tool Types Recommended	Example(s)
3. Nailing	Standard Farrier Tools + Safety Glasses	----
3A. Final Cut	<i>Either one of the following:</i>	
	12" Frame Hacksaw (With 14-18 TPI teeth) 	<ul style="list-style-type: none"> • Milwaukee #48-22-0050
4. Post-Shoeing Monitoring	Shoe Gap Gauge (allows monitoring of the shoe gap and informs when the maximum recommended ¼" (6mm) shoe gap is reached) 	<ul style="list-style-type: none"> • Bartek Shoe Gapper™ #SG-38D
	Adjustable Hoof Tester (to demonstrate degree of heel movement achieved with Twin Shoes) 	<ul style="list-style-type: none"> • Centaur Forge #CENTESTADJ

Note: A horse's acceptance of noise generating power tools should be known before using power tools for the final shoe cut